

## **Goods Disinfection Cabinet - Large**

## Goods Disinfection Cabinet / Eşya Dezenfeksiyon Kabini

## Datasheet / Teknik Özellikler



## FIELDS of USAGE

Offices, houses, banks, factories, hotels ... etc. It can be used anywhere disinfection wants.

MODEL	Goods Disinfection Cabinet - Large
ТҮРЕ	Bidirectional Surface Disinfection Cabinet
CLASS	-
PHYSICAL AND TECHNICAL FEATURES	
EXT. DIMENSIONS (W-L-H) (mm)	600 x 550 x 975
SHIPPACK SIZE (mm)	650 x 650 x 1050
DEVICE WIGHT (kg)	50
DISINFECTION TIME (s)	60
EFFECTIVE DISINFECTION TIME	8 000 hours
UV LAMB	2 pieces UV-C Lambs 250 – 260 nm
UV LAMB LIFETIME	9 000 hours

DISINFECTION RATE	%99.9	
DEVICE CHASSIS	Stainless steel	
SOUND LOUNDNESS (1 m Distance)	35 dB	
ELECTRICAL FEATURES	220 V <sub>RMS</sub> 50-60 Hz, 70W	
PROTECTION CLASS	IP20	
INSTALLATION FEATURE		
It starts working when emergy is given.		
CERTIFICATIONS		
CE CERTIFICATE	Yes	
AVAILABILITY TEST APPROVAL	Yes	
TSE SERVICE CERTIFICATE	-	
CARE PERIOD AND CARE KIT		
UV LAMB	It should be changed once in 1 year.	
	It should be clean with microfiber cloth once in 2 weeks.	
PRECAUTIONS		
The device is not suitable for children. Keep your children away from the device.		
The device is not suitable for your pets. Do not use on your pets.		
The device contains a high intensity UVC beam. While the device is operating, do not look.		
High intensity UVC rays can damage your skin. While the device is operating, do not touch it.		
UVC ray disinfects the area it sees. Putting the packages on top of each other in the device it cannot provide		
disinfection on all surfaces of your packages. Before operating the device make sure your packages are placed		
so that they can be seen by the UVC beam.		
The UVC beam does not affect the disinfection of the outer surface of the device. The outer surface of the		
device		

info@regi-tech.org